


# Parts catalog



# Index

- ① Axle and braking system (3-6)
- ② Pneumatic system (7-9)
- ③ Air compressor (10-12)
- ④ Chassis components (13-16)

# Axle and braking system



<b>Article number</b>	<b>4002</b>
<b>Article description</b>	
Complete wheel; rim and tyre, 205/65R17.5 ET0	



<b>Article number</b>	<b>3008</b>
<b>Article description</b>	
Brake booster 12 inch	



<b>Article number</b>	<b>1072</b>
<b>Article description</b>	
Height level sensor PLUS Axle relief system	



<b>Article number</b>	<b>3240</b>
<b>Article description</b>	
Brake cable 7.5 x 15 mm, 1.300 mm	

# Axle and braking system



<b>Article number</b>	<b>2004</b>
<b>Article description</b>	
Air spring C 92 mm	



<b>Article number</b>	<b>2008</b>
<b>Article description</b>	
Shock absorber	



<b>Article number</b>	<b>3241</b>
<b>Article description</b>	
Parking brake lever	



<b>Article number</b>	<b>M24X165</b>
<b>Article description</b>	
Leaf spring bolt M24 x 165	

# Axle and braking system



<b>Article number</b>	<b>2006</b>
<b>Article description</b>	
Leaf spring set	



<b>Article number</b>	<b>6021</b>
<b>Article description</b>	
Brake shoe set 5.5T GKH2	



<b>Article number</b>	<b>6023</b>
<b>Article description</b>	
Brake drum 5.5T GKH2	



<b>Article number</b>	<b>94169904</b>
<b>Article description</b>	
Silent block for leaf spring	

# Axle and braking system



<b>Article number</b>	<b>2003</b>
<b>Article description</b>	
Leaf spring clamp 3500PLUS Axle	



<b>Article number</b>	<b>2002</b>
<b>Article description</b>	
Clamp air suspension 3500PLUS Axle	



<b>Article number</b>	<b>2010</b>
<b>Article description</b>	
Leaf spring clamp Iveco Daily tractor	

# Pneumatic system



<b>Article number</b>	<b>3003</b>
<b>Article description</b>	
Overflow valve air tank PLUS Trailer	



<b>Article number</b>	<b>3193</b>
<b>Article description</b>	
Electrically controlled air dryer	



<b>Article number</b>	<b>3185</b>
<b>Article description</b>	
Sensor cable ABS 1.8 m	



<b>Article number</b>	<b>1073</b>
<b>Article description</b>	
Height level sensor cable 5 m	

# Pneumatic system



<b>Article number</b>	<b>3188</b>
<b>Article description</b>	
Height control valve and lever (E-TASC)	



<b>Article number</b>	<b>3194</b>
<b>Article description</b>	
Electronic Control Unit braking system (E-TCV)	



<b>Article number</b>	<b>3014</b>
<b>Article description</b>	
Quick release valve M16x1.5	



<b>Article number</b>	<b>3195</b>
<b>Article description</b>	
Pressure sensor E-CAS	

# Air compressor




<b>Article number</b>	<b>3028</b>
-----------------------	-------------

<b>Article description</b>
Compressor with electric motor 12V - 70 L



<b>Article number</b>	<b>3225</b>
-----------------------	-------------

<b>Article description</b>
Air compressor hose set with connections



<b>Article number</b>	<b>1063</b>
-----------------------	-------------

<b>Article description</b>
Carbon brushes with cables, air compressor



<b>Article number</b>	<b>3068</b>
-----------------------	-------------

<b>Article description</b>
Repair kit for air compressor


# Air compressor



<b>Article number</b>	<b>1129</b>
<b>Article description</b>	
Power relay 12V - 150A	



<b>Article number</b>	<b>10038</b>
<b>Article description</b>	
Anti-vibration mount, air compressor	



<b>Article number</b>	<b>10046</b>
<b>Article description</b>	
Pneumatic silencer	



<b>Article number</b>	<b>1055</b>
<b>Article description</b>	
MEGA / BF2 fuse holder	

# Air compressor



<b>Article number</b>	<b>3010</b>
-----------------------	-------------

<b>Article description</b>
----------------------------

Pressure regulator R13 braking system



<b>Article number</b>	<b>B14</b>
-----------------------	------------

<b>Article description</b>
----------------------------

Plug for pressure regulator



<b>Article number</b>	<b>QSL-6H</b>
-----------------------	---------------

<b>Article description</b>
----------------------------

Push-in elbow connector 6 mm



<b>Article number</b>	<b>3169</b>
-----------------------	-------------

<b>Article description</b>
----------------------------

Height adjustment 6mm elbow connector

# Chassis components



<b>Article number</b>	<b>1113</b>
<b>Article description</b>	
Flat Cable Aspöck connector - side marker lamps	



<b>Article number</b>	<b>1079</b>
<b>Article description</b>	
LED side marker lamp - Flat Cable Aspöck	



<b>Article number</b>	<b>1052</b>
<b>Article description</b>	
LED license plate light	



<b>Article number</b>	<b>1047</b>
<b>Article description</b>	
3-pin connector PLUS Axle Relief System	

# Chassis components



<b>Article number</b>	<b>1085</b>
<b>Article description</b>	
EBS connector 24V 5-pin	



<b>Article number</b>	<b>20003</b>
<b>Article description</b>	
Mounting bracket pin connector, right	



<b>Article number</b>	<b>20002</b>
<b>Article description</b>	
Mounting bracket pin connector, left	



<b>Article number</b>	<b>5015</b>
<b>Article description</b>	
Silent block mounting bracket pin connector	

# Chassis components



<b>Article number</b>	<b>20095 R</b>
<b>Article description</b>	
Universal rear light bracket, right (MAN/VW/MB/RT)	



<b>Article number</b>	<b>20083 L</b>
<b>Article description</b>	
Universal rear light bracket, left (MAN/VW/MB/RT)	



<b>Article number</b>	<b>20101 R</b>
<b>Article description</b>	
Rear light bracket, right (Iveco)	



<b>Article number</b>	<b>20100 L</b>
<b>Article description</b>	
Rear light bracket, left (Iveco)	


# Chassis components




<b>Article number</b>	<b>20013</b>
<b>Article description</b>	
Pin connector left	



<b>Article number</b>	<b>20014</b>
<b>Article description</b>	
Pin connector right	



<b>Article number</b>	<b>5004</b>
<b>Article description</b>	
Adjustable clamps rear side chassis	



**BE-Combi Systems**

+31(0)345 633644

aftersales@be-combi.nl

www.be-combi.com